

Complete units: Push-buttons ϕ 22mm


► SPRING RETURN - NON-ILLUMINATED

 Technical Info (p.106)

ϕ 32 MUSHROOM



L21AC01-1E01



WITH SINGLE POSITION CLIP

● Red	NC
● Green	NO
● Black	NO
● Yellow	NO

WITH THREE POSITION CLIP

● Red	NC
● Green	NO
● Black	NO
● Yellow	NO

Chrome Bezel
Part Number

Black Bezel
Part Number


L21AC01-1E01
L21AC02-1E10
L21AC03-1E10
L21AC04-1E10

L22AC01-1E01
L22AC02-1E10
L22AC03-1E10
L22AC04-1E10

ϕ 40 MUSHROOM



L22AD01-3E01



WITH SINGLE POSITION CLIP

● Red	NC
● Green	NO
● Black	NO
● Yellow	NO

WITH THREE POSITION CLIP

● Red	NC
● Green	NO
● Black	NO
● Yellow	NO

L21AD01-1E01
L21AD02-1E10
L21AD03-1E10
L21AD04-1E10

L22AD01-1E01
L22AD02-1E10
L22AD03-1E10
L22AD04-1E10

L21AD01-3E01
L21AD02-3E10
L21AD03-3E10
L21AD04-3E10


L22AD01-3E01
L22AD02-3E10
L22AD03-3E10
L22AD04-3E10

FLUSH-FLUSH

Twin touch



L62QA21-3E11



WITH INTERNATIONAL SYMBOLS

ⓘ Green	NO
Ⓢ Red	NC

WITH TEXT

● Green (START)	NO
● Red (STOP)	NC

L61QA21-3E11

L62QA21-3E11

L61QA21B-3E11


L62QA21B-3E11

FLUSH-PROJECTING

Twin touch



L61QB21-3E11



WITH INTERNATIONAL SYMBOLS

ⓘ Green	NO
Ⓢ Red	NC

WITH TEXT

● Green (START)	NO
● Red (STOP)	NC

L61QB21-3E11

L62QB21-3E11

L61QB21B-3E11

L62QB21B-3E11